

Instruction Manual

Product Number: FJT

Thank you for purchasing the THERMOS Vacuum Insulated Baby Straw Mug.


This page gives detailed handling instructions for the product.

For Household Use

For Cold Retention Only


Before Use

- Check that all the parts are included.
- Thoroughly clean all parts.



How to attach the gasket

- Leaking contents may soil your belongings, so attach the spout by following steps ① to ③. (P.11, P.12)



- ① Insert the tip of the spout through the △ hole in the cap body. The protrusion should be positioned above the ○ hole.



* The part cannot be attached if the orientation is incorrect.

- ② Press in the left and right sides of the straw attachment part. Then, push the protrusion into the ○ hole.

- ③ Pull the tip of the spout to prevent any gaps around the △ hole.

Part Names

Before use, check that all the parts are included.



Properly attach the dedicated spout and straw to the straw cap before use.

* Otherwise, the contents may leak.

Precautions

Read these precautions carefully before use and be sure to follow them.

Meaning of displayed markings

■ To ensure that this product is properly used, the extent of harm or damage caused by improper usage is categorized as follows.

 Warning	This mark indicates content that could result in death or serious injury.	 Caution	This mark indicates content that could result in minor injury or property damage.
--	---	--	---

■ Symbols

 Prohibited	This mark indicates actions to avoid.	 Required	This mark indicates actions that must be followed.
---	---------------------------------------	---	--

Warning



Do not use without parent or guardian supervision. Also, make sure it is not used as a toy by infants and toddlers.

* Small parts are a choking hazard and are at risk of being swallowed. Also, this behavior may result in injury.



Do not pour a hot drink into this product.

* Otherwise, hot liquid directly entering the mouth may result in burns.

* If the internal pressure rises, the straw cap may not open or may fly off, causing the contents to burst out and possibly resulting in burns, injury, or staining your belongings.



Be careful that the spout is not bitten through.

* Otherwise, it may cause choking if swallowed. The damaged spout may also leak, possibly staining your belongings or causing a lid malfunction.

Caution



Do not use this product for purposes other than drink storage.

* Doing so may cause injury.



Do not tilt or turn the main body upside down while the lid is open.

* Otherwise, the drink may spill out from the spout or air vent, possibly staining your belongings.

Precautions



Prohibited

Do not tilt the main body too much or hold it sideways when drinking.

* Otherwise, the drink may spill out from the spout or air vent, possibly staining your belongings.



Required

Attach only the dedicated parts to this product.

* Otherwise, the contents may leak, possibly staining your belongings.



Required

Properly attach the dedicated spout and straw to the straw cap.

(P.10 ③, P.11 ④)

* Otherwise, the contents may leak, possibly staining your belongings. It may also cause a lid malfunction.



Prohibited

Do not leave this product near a stove, gas heater, or other fire source.

* Doing so may cause burns. Additionally, the product may become deformed, possibly causing leaks that could stain your belongings.



Prohibited

Do not carry the product while the lid is open.

* If the main body is tilted or turned upside down, the drink may spill out from the spout or air vent, possibly staining your belongings.



Required

Make sure to prevent infants and toddlers from dropping the product.

* Doing so may cause injury.



Required

Avoid cramming large pieces of ice inside. Break them into smaller pieces.

* The maximum fill part on the mouth of the main body may become deformed, possibly causing leaks that could stain your belongings.



Required

Close the straw cap securely. (P.8 ④)


* Otherwise, the contents may leak, possibly staining your belongings.



Required

Keep the drink level below the pre-scribed position illustrated.

* Overfilling may cause the drink to overflow when closing the straw cap. Also, the contents may leak during use, possibly staining your belongings.



Prohibited

Avoid dropping the product, knocking it, or otherwise subjecting it to strong impact.

* Doing so may cause injury, or the contents may leak, possibly staining your belongings. It may also result in insufficient cold retention or a damaged straw cap.



Precautions

To care for the product, be sure to follow the instructions below.



Prohibited

Do not disinfect this product in the microwave. (except the spout, straw, and bottom cover)

- * The metal parts will spark, possibly resulting in damage to the microwave.
- * Heat may cause the product to become deformed, possibly causing leaks that could stain your belongings.



Required

Remove the bottom cover from the main body, clean them, and thoroughly dry the parts before reattaching them.

- * Otherwise, the water may seep, possibly staining your belongings or causing rust. Also, attaching the bottom cover while it is wet may cause the main body to fall out, possibly resulting in injury or damaging the product.

Never put the following inside the container.



Prohibited

Dry ice and carbonated drinks

- * If the internal pressure rises, the straw cap may not open or may fly off, causing the contents to burst out and possibly resulting in injury or staining your belongings.



Prohibited

Perishable items such as baby formula, milk, other dairy drinks, and fruit juice

- * Otherwise, the drink may spoil or go bad. Also, if a drink is left unattended for a long time, gases released through spoilage may increase the internal pressure until the straw cap cannot open or flies off, causing the contents to burst out and possibly resulting in injury or staining your belongings.



Prohibited

Tea leaves and pulp

- * If the crevices become clogged, the contents may leak, possibly staining your belongings.



Prohibited

Do not put this product in the microwave. (except the spout, straw, and bottom cover)


- * The metal parts will spark, possibly resulting in damage to the microwave.
- * Heat may cause the product to become deformed, possibly causing leaks that could stain your belongings.



Prohibited

Never modify, disassemble, or repair the product.

- * Doing so may cause damage or result in an accident.



Prohibited

Do not swing around the product by the handle.

- * Swinging the product around may cause it to strike the people around you, possibly causing injury.

Precautions



Prohibited

Do not turn the product upside down while holding the bottom cover.

* Doing so may cause the main body to fall out, possibly resulting in injury or damaging the product.



Prohibited

Do not leave a drink in this product for a long time.

* Otherwise, the drink may spoil or go bad. Also, if the internal pressure rises due to gases released through spoilage, the straw cap may not open or may fly off, causing the contents to burst out and possibly resulting in injury or staining your belongings.



Prohibited

Do not attach or remove the straw cap while the lid of the straw cap is open.


* Deformation or damage may cause leaks, possibly staining your belongings.



Prohibited

Avoid using this product if you hear sloshing sounds coming from inside of the double-layered vacuum structure (vacuum layer).

* If liquid from the vacuum layer seeps into the main body, consuming it may cause health issues.



Required

Do not leave your beverage for too long inside.

* Otherwise, the drink may spoil or go bad.



Required

When placing this product in a bag, make sure that the button will not be pressed due to other items inside the bag.

* Otherwise, the contents may leak, possibly staining your belongings.



Prohibited

Do not remove the straw cap unit while holding the handle.

* The handle may detach, causing the main body to fall and stain your belongings.



Required

Properly attach the handle. (▶▶▶ P.7 ③)

* Otherwise, the straw cap may not attach properly, possibly causing leaks that could stain your belongings.

Notes on Use

Refrain from inserting soups and other high-salt content items into the container.

* The main body uses stainless steel for its interior lining. However, exposure to salt may potentially cause rusting and diminish its ability to keep beverages cold for an extended period.

Due to the product's structure, water droplets (condensation) may form on the straw cap when humidity is high. Please handle with care.

When placing the product in a bag, place it upright to prevent any potential leaks.

If the cold retention is reduced, stop using the product.


Before going out, turn the product upside down to check for leaks.

* If the product leaks, check the items listed in "In This Case" on P.14.

Be aware that strong shaking or changes in the temperature and pressure inside the main body can cause the air inside to expand and increase pressure, which may cause the drink to spill out from the spout tip when opening the lid.

Do not peel off the protective sheet at the bottom of the main body.

* The product may lose its cold retention.



Protecting sheet


Do not put this product in the freezer.

* Doing so may result in damage or insufficient cold retention.

How to Use

1 Removing the straw cap

Twist the straw cap in the direction of the arrow to remove it.




Before Use

- Thoroughly clean the straw cap and the inside of the main body. (P.9)
- Confirm that the spout and straw are properly attached. (P.10 ③, P.11 ④)

2 Pour in your drink

Keep the drink level below the prescribed position illustrated. Overfilling may cause the drink to overflow when closing the straw cap.

Point Before inserting the content, insert a small amount of cold water into the main body to precool the inside for about 1 minute. Doing so will increase its cold retention ability.




3 When attaching the handle

Align the indents on the main body with the ridges on the handle.

* The product can be used without the handle.

Caution

- * If the handle is not attached in the correct position, the straw cap unit will not close properly, possibly causing leaks that could stain your belongings.
- * The handle is not fixed to the main body. When removing the straw cap, do not lift the main body by holding the handle. Otherwise, the main body may detach, possibly staining your belongings.




How to Use

4 Closing the straw cap

With the lid closed, twist the straw cap in the direction of the arrow and close it securely.

⚠ Caution


Be sure to hold the main body while closing it. If you try to close the straw cap by holding the handle, the handle will shift position, preventing the straw cap from closing properly.



5 Drink your beverage

① With the main body upright, press the **bottom of the button**. When you release the button, the lid opens and the spout pops up. (Move the lid to the position where it stays fixed.)

② Drink from the spout.




6 When finished drinking

With the main body upright, press the lid until you hear a click to close it securely.

⚠ Caution

* To prevent the drink from spilling when the product is tipped, do not leave the lid open.



Product Care

To prevent smells, stains, and mold and keep the product clean for a long time, always properly maintain it after use.

- After use, immediately clean the product and thoroughly dry it.
- Remove all parts, and clean them thoroughly.
- If you will not be using the product for a long time, clean it thoroughly to remove any dirt, thoroughly dry it, and then store it in a place that is not too hot or humid.

Part name How to wash		Straw cap		Main body		Handle	Bottom cover
		Lid Cap body	Spout Straw	Inside	Outside		
Running water rinse		✓	✓	✓	✓	✓	✓
Soak and wash		✓	✓	✓	✗	✓	✓
Bleach	Oxygen-based	✓	✓	✓	✗	✓	✓
	Chlorine-based	✓	✓	✗	✗	✓	✓
Chemical disinfection		✓	✓	✗	✗	✓	✓
Microwave disinfection		✗	✓	✗	✗	✗	✓
Boiling disinfection		✓	✓	✗	✗	✓	✓
Dishwasher* Dish dryer		✓	✓	✗	✗	✓	✓
Heat resistance		100°C	140°C	—	—	100°C	140°C

* Before using a dishwasher, dryer, and detergent, check the instruction manuals to confirm the conditions of washable parts (heat resistance, etc.) and the washing method.

Precautions during Product Care

Before performing product care, read these precautions carefully and be sure to follow them.

 **Do not boil the main body.**
* Water may enter the gaps, and the product may rust or lose its cold retention.

 **Do not leave the main body in water.**
* Water may enter the gaps, and the product may rust or lose its cold retention.

 **Do not use chlorine bleach for the main body.**
* Otherwise, the product may rust or lose its cold retention.

 **Do not use paint thinner, benzine, steel scrubbers, polishing powder, or cleansers to clean this product.**
* Doing so may cause rust, scratches, or damage.

 **Do not use a dishwasher or dish dryer to wash the main body.**
* Heat may cause the product to become deformed, possibly causing leaks that could stain your belongings. Additionally, the paint, printing, or stickers may peel off.

 **Do not disinfect this product in the microwave. (except the spout, straw, and bottom cover)**
* The metal parts will spark, possibly resulting in damage to the microwave.
* Heat may cause the product to become deformed, possibly causing leaks that could stain your belongings.

 **Do not use bleach to clean the outside of the main body.**
* The paint, printing, or stickers may peel off.


Product Care

Attaching and removing the spout and straw

■ How to remove the straw cap (P.7 ①)


① How to remove the spout

With the lid open, hold the straw attachment point on the inside of the spout and pull it out from the cap body.



② How to remove the straw

Remove the straw from the spout.




③ How to attach the straw

Insert the straw fully to the base of the straw attachment.



Caution

Confirm that the spout is not damaged.




Product Care

4 How to attach the spout


* If the spout is not properly attached, the contents may leak.
Attach it securely according to the instructions.

- ① With the lid of the straw cap unit open, orient the tip of the spout towards the button and insert it into the  hole. The protrusion should be positioned above the  hole.


* The part cannot be attached if the orientation is incorrect.



- ② Press in the left and right sides of the straw attachment part. Then, push the protrusion on the button side into the  hole.




- ③ Pull the tip of the spout to prevent any gaps around the  hole.




Product Care

- ④ Press the button and confirm that the protrusion on the spout is properly sticking out from the  hole. If it is not sticking out, the spout is not attached correctly.

Start again from ①.



! Check




The lid was closed without attaching the spout.

If the spout is not attached, the lid will not open, even when you press the button.

- ① Lift the lid while pressing the button.
② Release the button, and the lid will open.


■ How to attach the spout and straw (👉 P.10 ③, P.11 ④)



Product Care


Normal product care

- Carefully wash with neutral dish detergent that is diluted in lukewarm water, and after rinsing, drain out all of the water and thoroughly dry the parts.

Straw cap Lid, cap body, spout, straw Handle, bottom cover 	Lid, cap body, handle, bottom cover Use a soft sponge. Spout, straw After cleaning with a dedicated straw brush, thoroughly rinse the inside with a strong stream of water.
Main body 	Remove the bottom cover, and use a soft sponge or bottle brush. Wipe the outside with a dry cloth immediately after washing. * Otherwise, water droplets may leave marks or cause rust.

Thorough product care

- Use kitchen bleach in accordance with its instruction manual, and after rinsing, drain out all of the water and thoroughly dry the parts.

Straw cap Lid, cap body, spout, straw Handle Bottom cover 	For tea stains, etc. Mix bleach and water in a bowl or other container, and soak each of the parts. (Approx. 30 min.)
Main body interior 	For tea stains, etc. Use oxygen bleach only on the inside. (Approx. 30 min.)  Prohibited: Chlorine bleach Do not attach the straw cap. * Doing so is dangerous, as pressure will rise inside the main body, and the straw cap may suddenly fly off. Specks of red rust This is caused by a buildup of iron and other impurities in the water. Pour a mixture of 90% lukewarm water and 10% vinegar into the main body, and then wait about 30 minutes before rinsing it well. Gritty residue This is caused by a buildup of calcium and other impurities in the water. Pour a mixture of lukewarm water and 1% to 2% citric acid into the main body, and then leave it for about 3 hours without attaching the straw cap before rinsing it well.

In This Case

If an uncertain situation arises,
check the items below.

Issue	Cause	Solution
The straw cap is leaking.	The straw cap or lid is not securely closed.	Close the straw cap and lid securely. ( P.8 ④ ⑥)
	Too much drink is inside.	Keep the drink level below the prescribed amount. ( P.7 ②)
	The spout has slipped, or it is not attached securely.	Securely attach the spout in the proper position. ( P.11, P.12)
	The straw cap or spout is damaged or worn.	Purchase replacement parts, which are sold separately. ( P.15)
	Some drink remains inside the spout.	Make sure no drink remains inside the spout before closing the lid.
I cannot drink the beverage.	The straw is detached.	Be sure to attach the straw and push it in firmly. ( P.10 ③)
The inside of the main body is discolored.	The interior is stained.	Use oxygen bleach to clean the interior. ( P.13)
	Specks of rust are attached to the interior.	This is caused by a buildup of iron and other impurities in the water. Use vinegar to clean the interior. ( P.13)
	Gritty residue is attached to the interior.	This is caused by a buildup of calcium and other impurities in the water. Use citric acid to clean the interior. ( P.13)
The cold retention is ineffective.	The drink put inside was not cold enough.	Pour a cold drink into this product. Precooling the inside of the main body before use is also effective.
	There is not enough drink.	Increase the amount of ice or drink.
The product smells bad.	The inside of the main body or the straw cap is dirty.	Clean the product and thoroughly dry it. If this does not remove the smell, follow the product care instructions and use oxygen bleach. ( P.13)
The spout or straw is discolored.	The gasket or straw is stained or moldy.	Use bleach to clean the gasket. ( P.13) If the dirt or mold cannot be removed, dispose of the gasket and purchase a replacement, which is sold separately. ( P.15)

How to Purchase Replacement Parts (Sold Separately)

Confirm the product number and product name, and then make a purchase using the method specified below.

(The product number and color name are indicated on the sticker attached to the bottom of the main body.)

① THERMOS online shop (replacement part sales)

https://www.shopthermos.jp/shop/goods/p_search.aspx

Order parts from the URL above. (Please be aware that the available parts are limited.)

Web address: <https://www.thermos.jp/>

To improve the product, some of its specifications may be changed without prior notice. Therefore, please be aware that the illustrations in this guide may differ slightly from the actual product.